

How to switch the Anytone AT-5555 (v.6.0) Transceiver from 10-metre Amateur Bands to CB Bands

1. Ensure the radio is off
2. Press and Hold both the FUNC and EMG-S/RF buttons, and turn on the radio



3. Release the two buttons; you should have alphanumeric characters showing on the display: "1bAnd"



Rotate the Channel Knob until you get "2bAnd"



4. Press and hold the FUNC key;

The screen will display rES...



...then display rEnd.



...release the FUNC key.

The Expansion Operation has now been successfully performed.





Note: to return the AT-5555 to Amateur Radio 10metre frequencies, go through the above steps, selecting 1bAnd instead of 2bAnd.



= Amateur Radio 10metre



= CB Frequencies.

Note: The Anytone Software (v.6.0) can be used to change/amend/add channels to either the “1bAnd” or the “2bAnd” frequency settings.

The “2bAnd” set of frequencies will only give you 40 channels. 20 extra channels can be (if legally allowed) added to, for the full complement of 60 channels.

Nevada Radio, 05 September 2012
MORAV