

CB Taajuuslista MOCOMA 27 / 45 By MAVO

20,480 Jako Synt...

Ch.	jako	D	Bin	hex
1	330	26,965	-01001010	4A
2	329	26,975	-01001001	49
3	328	26,985	-01001000	48
4	326	27,005	-01000110	46
5	325	27,015	-01000101	45
6	324	27,025	-01000100	44
7	323	27,035	-01000011	43
8	321	27,055	-01000001	41
9	320	27,065	-01000000	40
10	319	27,075	-00111111	3F
11	318	27,085	-00111110	3E
11A	317	27,095	-00111101	3D
12	316	27,105	-00111100	3C
13	315	27,115	-00111011	3B
14	314	27,125	-00111010	3A
15	313	27,135	-00111001	39
16	311	27,155	-00110111	37
17	310	27,165	-00110110	36
18	309	27,175	-00110101	35
19	308	27,185	-00110100	34
20	306	27,205	-00110010	32
21	305	27,215	-00110001	31
22	304	27,225	-00110000	30
23	301	27,255	-00101101	2D
24	303	27,235	-00101111	2F
25	302	27,245	-00101110	2E
26	300	27,265	-00101100	2C
27	299	27,275	-00101011	2B
28	298	27,285	-00101010	2A
29	297	27,295	-00101001	29
30	296	27,305	-00101000	28
31	295	27,315	-00100111	27
31A	271	27,555	-00001111	F
32	294	27,325	-00100110	26
33	293	27,335	-00100101	25
34	292	27,345	-00100100	24
35	291	27,355	-00100011	23
36	290	27,365	-00100010	22
37	289	27,375	-00100001	21
38	288	27,385	-00100000	20
39	287	27,395	-00011111	1F
40	286	27,405	-00011110	1E
41	305	27,215	-00110001	31
42	304	27,225	-00110000	30

Normaali 1...22 CH

Ryh	HEX	Näyttö
0	4A	1
0	49	2
0	48	3
0	46	4
0	45	5
0	44	6
0	43	7
0	41	8
0	40	9
0	3F	10
0	3E	11
0	3D	11A
0	3C	12
0	3B	13
0	3A	14
0	39	15
0	37	16
0	36	17
0	35	18
0	34	19
0	32	20
0	31	21
0	30	22
0	00	23

Lisä 21...40 CH

Ryh	HEX	Näyttö
1	4A	21
1	49	22
1	48	23
1	46	24
1	45	25
1	44	26
1	43	27
1	41	28
1	40	29
1	3F	30
1	3E	31
1	3D	8A
1	3C	32
1	3B	33
1	3A	34
1	39	35
1	37	36
1	36	37
1	35	38
1	34	39
1	32	20
1	31	21
1	30	22
1	00	23

Huom: Ch 23 antaa impulssin ryhmän vaihtoon 1...22 / 21...40